


Captured Sign Frame

Parts List:



Required Tools

1. Remove the two (2) screws from the Frame by turning counter-clockwise using the supplied allen wrench. See figure A.
2. Lift the Top Frame Assembly up off the Lower Frame. See figure B.
3. Sandwich graphic between supplied acrylic sheets and slide into frame channels as shown. See figure C.
4. Replace the Top Frame Assembly onto the lower frame. See figure D.
5. Place the two (2) screws into the frame and tighten using the supplied allen wrench. See figure E.
6. Place Frame on top of post by sliding the sign mount legs into the grooves of the post. If desired, tighten the set screw on mount leg.

