

Captured Sign Frame: Inserting Media

Parts List:



Captured Sign Frame
(Post-mounting option may vary.)



Required Tools

1. Remove the two (2) screws from the Frame by turning counterclockwise using the supplied Allen wrench. See figure A.
2. Lift the Top Frame Assembly up off the Lower Frame. See figure B.
3. Sandwich graphic between supplied acrylic sheets and slide into frame channels as shown. See figure C.
4. Replace the Top Frame Assembly onto the lower frame. See figure D.
5. Place the two (2) screws into the frame and tighten using the supplied Allen wrench. See figure E.

