

7ft. Recessed Wall Mount

Parts List:



Required Tools

Note: This product is recommended for drywall only. We offer other wall mounts that are more appropriate for metal and wood surfaces.

1. Select an area of drywall free from wiring and conduits and determine the position for your Recessed Wall Mount. Measure a rectangle 2-7/8" wide by 4-3/8" wide. The opening should be just large enough to accommodate the Wall Mount casing. (Illustration A)
2. Using a drywall utility knife, cut the rectangle out of the drywall and make sure that the depth will accommodate the depth of your Wall Mount. (Illustration B)
3. The Wall Mount should fit snugly into the recessed wall, exposing only the flush back plate and belt end. Using four #10 screws [anchors recommended] secure the Back Plate to the wall, exposing only the Belt End for a clean, flush look. (Illustration C)
4. To create a temporary barricade, pull the belt end out and attach it to a Beltrac post or Wall Receptacle. (Illustration D)

