




# Side-mount Merchandising Bowl

## Parts List:



## Required Tools

1. From the bottom, insert Screw through Swing-arm, 1st Washer, Bowl, and 2nd Washer. (*Illustration A*)





2. If your Bowl comes with a Sign Holder, please follow instructions on back of this sheet and attach Sign Holder's Sign Base. With a Sign Holder, there is no need to use the Nut.

3. From the top, tighten the Acorn Nut\* onto the exposed end of the Screw.  
(*Illustration B*)

\*The Nut contains locking glue which is activated once tightened.


4. Determine the desired position of the Bowl on the Beltrac® Post. Attach the Bowl to Post by loosening the hinge grip with the supplied Allen wrench. Insert hinge grip into post groove and re-tighten. (*Illustration C*)

5. Adjust the angle of the Side-swing Arm by loosening the top screw on the hinge grip. Re-tighten to secure in desired position. (*Illustration D*)



# Sign Holder for Merchandising Bowl

## Parts List:



Bowl with mounting assembly as described on other side of this sheet.



Sign Holder with Magnetic Foot



Sign Base



Goggles



Phillips Crosshead Screw Driver

## Required Tools

1. Install Sign Base on top of 2nd Washer. Tighten screw to secure. (*Illustration E*)
2. Remove Magnetic Foot from the acrylic Sign Holder. Insert graphic into Sign Holder. Replace Magnetic Foot. Graphic size: 8" x 2.5" (*Illustration F*)
3. Place Sign inside Bowl, attaching Sign Holder to Base by means of the magnet inside the Sign Foot. (*Illustration G*)

