
Assembly Instructions • Assembly Instructions • Assembly Instructions

Basic Rectractable Post

Parts List:




Set Screws (pre-installed)


Basic Post






- **1.** Insert base of post into opening in Base Assembly. See Figure A.
- **2.** Lay post on its side. See Figure B.
- **3.** Tighten all 3 set screws using Allen Wrench (provided). See Figure C.
- **4.** Once post is secured to base it becomes a permanent connection.







© 2025 Lavi Industries All Rights Reserved. **87-024** 2.18.09 Beltrac Rectractable Posts. 5885 E. Houston Street | San Antonio, TX 78220 800.624.6225 | 877.ASK.LAVI | 661.257.7800 sales@lavi.com | www.lavi.com

